

# Wood-Look Umbrella Tilt Replacement AIS

Tools required



1. Electrical driller with cross head

1. Take off the finial

Replace the canopy



2. Take down the umbrella canopy from tableting



3. Press the fixed clips on the bracket to slip off all the snap button on the taps



4. Use internal hexagonal wrench to loosen the rivet from the rib end, take off the overall canopy.



1. There are six screw spikes in the tilt, three at each part.

2. Remove the three screws from the upper part of tilt.

3. Remove the three screws from the lower part of tilt.

Replace the Tilt



4. Grasp the pole on both end of the tilt mechanism and turn left and right to pull out the lower pole, then remove the tilt from the u



Replace the Tilt

5. Then replace the new tilt mechanism,insure that proshade logo is on the lower part of the tilt of mechanism



6. Grasp the upper pole and insert the upper of the tilt mechanism



Replace the Tilt

7. Use driller to assemble back the screws.



8. Finished

